

# FGD-0108

## Temperature and Humidity Sensor Quick Installation Guide

Informational Reference for Authorized Installers and Fitters

---

### 1. Overview


FGD-0108 temperature and humidity sensor is compact and user friendly. It measures and displays both ambient temperature and relative humidity at the same time.



#### Main Features:

1. 12 - 24V DC Main Power Input
  2. Temperature Sensing Range: 0°C – 50°C (-32°F– 122°F) (Accuracy: ± 0.3°C at 25°C)
  3. Humidity Sensing Range: 0 – 100% RH (Accuracy: ± 3% RH at 25°C)
  4. Temperature Display Unit: Degree Celsius or Degree Fahrenheit
  5. Normally Open (NO) Solid State Output
  6. Dimension: 86 x 86 x 33mm
  7. Weight: 105g
  8. Housing: White Plastic
-

## 2. Wiring Connection



- 1: 12V DC+
- 2: GND
- 3: Temperature NO
- 4: Temperature COM
- 5: Humidity NO
- 6: Humidity COM

---

### 3.1 Configure High / Low Temperature Limit

1. Press and hold **MENU** for 3 seconds
2. Use ▲ and ▼ to set high temperature limit ----- 

Set 35°C HI
----------------
3. Press **ENTER** to save, press **MENU** to go to next page
4. Use ▲ and ▼ to set low temperature limit ----- 

Set 15°C Lo
----------------
5. Press **ENTER** to save, press **MENU** to go to next page
6. Use ▲ and ▼ to set temperature hysteresis width ----- 

Set 0.3°C dL
-----------------
7. Press **ENTER** to save, press **MENU** for 5 times to exit

### 3.2 Configure High / Low Humidity Limit

1. Press and hold **MENU** for 3 seconds and then press **MENU** for 3 times
2. Use ▲ and ▼ to set high humidity limit ----- 

Set HI 80%
---------------
3. Press **ENTER** to save, press **MENU** to go to next page
4. Use ▲ and ▼ to set low humidity limit ----- 

Set Lo 30%
---------------
5. Press **ENTER** to save, press **MENU** to go to next page
6. Use ▲ and ▼ to set humidity hysteresis width ----- 

Set dL 3%
--------------
7. Press **ENTER** to save, press **MENU** twice to exit

### 3.3 Reset to Factory Default

1. Press and hold **MENU** for 3 seconds and then press **MENU** for 6 times
  2. Press **ENTER** to restore to factory default ----- 

dEFt
------
  3. Press **MENU** to exit
-

---

### 3.4 Configure Temperature Display Unit °C / °F

1. Press and hold ▲ and **ENTER** for 3 seconds

2. Press ▼ for **Degree C** / ▲ for **Degree F** ----- 

Set °C
--------

 / 

Set °F
--------

3. Press **ENTER** to save, press **MENU** for 3 times to exit

### 3.5 Configure Humidity Display RH.

1. Press and hold ▲ and **ENTER** for 3 seconds and then press **MENU**

2. Press ▼ for **no RH display** / ▲ for **RH display** ----- 

Set
-----

 / 

Set RH
-----------

3. Press **ENTER** to save, press **MENU** twice to exit

### 3.6 Temperature and Humidity Offset Value Setting

1. Press and hold **MENU** and **ENTER** for 3 seconds

2. Use ▲ and ▼ to input password: 11 and then press **ENTER** ----- 

PS 11
----------

3. Use ▲ and ▼ to input temperature offset value ----- 

ERR 0.0°C SET
------------------

4. Press **ENTER** to save, press **MENU** to go to next page

5. Use ▲ and ▼ to input humidity offset value ----- 

ERR RH SET 0.0 %
---------------------

6. Press **ENTER** to save, press **MENU** to exit