

# SENSAPHONE Monitoring Sensor

## General Accessories

### Magnetic Reed Switch



#### Description

The magnetic reed switch may be used with all Sensaphone models to detect any unauthorized entry or intrusion. They are usually installed on doors and windows to detect their opening and closing. Several magnetic reed switches may be wired in series.

#### Package Contents

- (1) Sensor
- (1) Spacer
- (1) Sensor Casing
- (1) Magnet
- (4) Mounting Screws
- (1) Installation Instructions

#### Specifications

**Dimensions:**

Part w/ screw terminals:

2 1/2" x 3/4" x 1/2"

Part w/ magnet:

2 1/2" x 3/4" x 5/8"

**Housing:**

White plastic

**Compatibility:**

All Sensaphone models

\*Specifications subject to change without notice

Magnetic Reed Switch . . . . . FGD-0006